



© Copyright 2021 ATEN® International Co. Ltd.
ATEN and the ATEN logo are registered trademarks of ATEN International Co., Ltd.
All rights reserved. All other trademarks are the property of their respective owners.

Released: 06/2021



Package Contents

- 1 UH3230A Multiport Dock with Power Charging
- 1 power adapter
- 1 USB-C cable
- 1 user instructions

Support and Documentation Notice
All information, documentation, firmware, software utilities, and specifications contained in this package are subject to change without prior notification by the manufacturer.
To reduce the environmental impact of our products, ATEN documentation and software can be found online at <http://www.aten.com/download/>

Technical Support
www.aten.com/support

Scan for more information

ATEN Website



The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

A Hardware Overview

- 1 USB 3.2 Gen 1 Type-A ports.
- 2 Headphone jack with microphone¹
- 3 USB-C host port
- 4 DisplayPort out
- 5 HDMI out
- 6 VGA out
- 7 Ethernet port
- 8 audio out¹
- 9 USB-C PD 3.0 DC-in port² (supports USB 3.0 Gen 1 Type-C port data transfer)
- 10 power jack

Note:

- When both the audio out and headphone jack with microphone are connected to an audio device, the latter takes precedence over the former.
- To use the USB-C DC-in port, an additional USB-C PD (LPScertified) power adapter required.

Host Requirement

USB-C enabled computer or smartphone / tablet with one of the following operating systems:

- Windows® 10 (32-bit / 64-bit) with 7th-Gen Intel Core Processor or above
- MacOS X 10.12 or later
- iPadOS 13.1 or later
- Android 8.0 or later

Note: To transmit video through a USB-C port, make sure your computer supports DP Alt Mode over the USB-C port, and that it has been enabled.

B Installation

- Supply power to the unit, thereby turning it on, by plugging the power adapter provided into a power source, and plug its cable into the unit's power jack.
- Connect a USB-C enabled computer to the unit's USB-C host port.
- Connect up to 2 displays to the VGA, HDMI, and DisplayPort output ports.

Note:

- The recommended lengths of the cables used to connect to the displays shall not exceed 5 m.
- For MacOS, only 1 display can be used in Extended Mode; when 2 displays are connected, only Mirror Mode is supported.
- Connect an Ethernet cable to the unit's Ethernet port for internet access.
- Connect USB peripheral devices to the unit's USB 3.2 Gen 1 Type-A ports.
- Connect the unit to an audio device by doing one of the following:
 - A. Connect a set of speakers to the unit's audio jack.
 - B. Connect a headphone to the unit's headphone jack with microphone.
- (Optional) Connect a USB-C PD power adapter or a USB-C peripheral device to the unit's USB-C DC-in port, respectively for power redundancy or peripheral device operation.

C Operation

Monitor / Sound Settings for Mac

External Monitor Settings:

Option 1: Extend Mode

- Open **System Preferences** and click **Displays**.
- Click on **Arrangement** to change the position of the connected displays.

Option 2: Mirror Mode

- Open **System Preferences** and click **Displays**.
- Click on **Arrangement**.
- Select and check **Mirror Displays**.

External Sound Settings

- Open **System Preferences** and click **Sound**.
- Click on **Arrangement** to change the sound output device to the UH3230A.

UH3230A

11- 포트 USB-C 도킹스테이션
(랩탑 충전 지원)
간단 사용 설명서




© Copyright 2021 ATEN® International Co. Ltd.

ATEN and the ATEN logo are registered trademarks of ATEN International Co., Ltd.
All rights reserved. All other trademarks are the property of their respective owners.


Released: 06/2021

A Hardware Overview



Front View

B Installation



Package Contents

- 1 UH3230A 11- 포트 USB-C 도킹 스테이션 (랩탑 충전 지원)
- 1 전원 어댑터
- 1 USB-C 케이블
- 1 사용자 매뉴얼

Support and Documentation Notice

All information, documentation, firmware, software utilities, and specifications contained in this package are subject to change without prior notification by the manufacturer.

To reduce the environmental impact of our products, ATEN documentation and software can be found online at <http://www.aten.com/download/>

Technical Support

www.aten.com/support

Scan for more information

ATEN Website



The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

A 하드웨어 리뷰

- ① USB 3.2 Gen 1 Type-A 포트
- ② 헤드폰 잭 with 마이크 ¹
- ③ USB-C 호스트 포트
- ④ DisplayPort 출력
- ⑤ HDMI 출력
- ⑥ VGA 출력
- ⑦ 이더넷 포트
- ⑧ 오디오 출력 ¹
- ⑨ USB-C PD 3.0 DC 입력 포트 ² (USB 3.2 Gen 1 Type-C 포트 _ 데이터 전송 지원)
- ⑩ 전원 잭

Note:

1. 전 / 후면 오디오 잭에 이어폰 혹은 오디오 출력 장치가 연결 시 , 전면 오디오 잭에서만 오디오가 출력됩니다 .
2. USB-C PD (LPS 인증) 전원 어댑터는 기본 패키지에 포함되어 있지 않으며 , 별도 구매가 필요합니다 .

호스트 요구 사항

아래의 운영 체제를 지원하는 USB-C 지원 PC 혹은 스마트폰 / 태블릿 :

- Windows® 10 (32-bit / 64-bit) with 7th-Gen Intel Core Processor 이상
- MacOS X 10.12 이상
- iPadOS 13.1 이상
- Android 8.0 이상

Note: USB-C 포트를 통해 정상적으로 비디오를 출력하려면 연결하려는 장치의 USB-C 포트가 DP Alt Mode 를 지원하는지 반드시 확인하십시오 .

B 하드웨어 설치

- ① 패키지에 포함되어 있는 전원 어댑터에 전원 코드를 연결하고 , 장치의 전원 잭에 연결합니다 .
- ② USB-C 를 지원하는 PC 를 장치의 USB-C 호스트 포트에 연결합니다 .
- ③ VGA, HDMI 및 DisplayPort 출력 포트에 최대 2 개의 디스플레이를 연결합니다 .

Note:

1. 디스플레이에 연결하는 데 사용되는 케이블의 길이는 5m 를 초과하지 않는 것을 권장합니다 .
2. MacOS 의 경우 확장 모드에서는 1 개의 디스플레이만 사용할 수 있으며 , 2 개의 디스플레이가 연결된 경우 복제 모드만 지원됩니다 .
- ④ 인터넷 연결을 위해 이더넷 케이블을 장치의 이더넷 포트에 연결합니다 .
- ⑤ USB 주변 장치를 장치의 USB 3.2 Gen 1 Type-A 포트에 연결합니다 .
- ⑥ 아래와 같은 방법 중 하나를 택하여 오디오 장치를 연결합니다 :
A. 스피커를 장치의 후면 오디오 잭에 연결합니다 .
B. 헤드폰을 장치의 전면 오디오 잭에 연결합니다 .
- ⑦ (선택 사항) 전원 이중화를 위해 USB-C PD 전원 어댑터 또는 USB-C 주변 장치를 장치의 USB-C DC 입력 포트에 연결합니다 .

C 작동

Mac 모니터 / 사운드 설정

외부 모니터 설정 :

Option 1: 확장 모드

1. 시스템 환경 설정을 열고 디스플레이를 클릭합니다 .
2. 연결된 디스플레이의 위치를 변경하려면 배열을 클릭합니다 .

Option 2: 복제 모드

1. 시스템 환경 설정을 열고 디스플레이를 클릭합니다 .
2. 배열을 클릭합니다 .
3. 복제 화면을 선택하고 확인을 누릅니다 .

외부 사운드 설정

1. 시스템 환경 설정을 열고 사운드를 클릭합니다 .
2. 배열을 클릭하여 사운드 출력 장치를 UH3230A 로 변경합니다 .